



DODGE CARAVAN RS

REAR AIR DEFLECTOR

Genuine Accessories

 A	 B	 X2 C	
 X1 D	 X1 E	 X4 F	 X4 G
 X4 H	 X4 I	 X1 J	 X1 K 4MM

Tools Required / HERRAMIENTAS NECESARIAS / OUTILS NECESSAIRES

 #2 #3		 9/32" 7mm
		 9/16"

© DAIMLERCHRYSLER



DODGE CARAVAN RS

REAR AIR DEFLECTOR

Genuine Accessories

1 Hand holding the air deflector against the rear window.

2 Deflector is positioned on the rear window with label **B** pointing to the top edge.

3 Deflector is shown with label **B** pointing to the top edge.

4 Deflector is shown with label **B** pointing to the top edge.

5 Hand marking the deflector with a pencil. Label **B** points to the top edge.

6 Hand using a power drill to drill a hole. Callouts include: 9/32" 7mm drill bit, 1/8" 3.1mm depth, and a 4mm hex key.



DODGE CARAVAN RS

REAR AIR DEFLECTOR

Genuine Accessories

7 Hand holding the deflector against the rear window with label **B** pointing to the top edge.

8 Deflector is shown with label **B** pointing to the top edge. Callouts include: 1. Spring and screw, 2. Screwdriver and paint, PM12-A, DRY TIME 5-10 min.

9 Deflector is shown with label **B** pointing to the top edge. Callouts include: 9 ft. lb. torque, 4x screws, 9/16" wrench, and 4MM hex key. Labels **J** and **I** point to the spring and screw respectively.

10 Deflector is shown with label **B** pointing to the top edge. Callouts include: **E**, **C**, **D**, and **C** pointing to various components.

11 Deflector is shown with label **B** pointing to the top edge. Callouts include: 24 in. lbs. 2 ft. lbs. torque, and label **G** pointing to the top edge. An arrow labeled **FRONT** points to the left.

12 Deflector is shown with label **B** pointing to the top edge. Callouts include: 4x screws, 8 in. lbs. torque, and label **A** pointing to the top edge. Label **H** points to the screw.