
Chrome Door Handle Overlays

Contents:

Door Handle Covers Door Buttons

- 1. Installation should be done when temperature is between 65° 110° F (18°-43° C). Clean mounting surface with rubbing alcohol. Avoid areas to which the product will not be adhered. THIS MUST BE DONE FOR ADHESIVE TAPE TO PROPERLY STICK. FAILURE TO CLEAN COULD RESULT IN POOR ATTACHMENT AND FAILURE OF PRODUCT TO STAY ATTACHED. Allow areas to dry completely before attaching door handles.
- 2. Test fit the Door Handle Cover to the vehicle before removing the plastic backing film. This will aid in aligning the piece properly before securing with the two sided 3M[®] tape. Remove plastic backing film from the affixed two sided 3M[®] tape on the inside of one door handle. The plastic film can be removed easier with the aid of a knife or cutting blade. Peel from leading edges and pull away from tape.



3. Position Door Handle Cover on door handle and apply pressure to secure to vehicle.



4. Remove plastic backing film from the affixed two sided 3M[®] tape on the inside of one Button Cover. Center the Button Cover on door handle button and apply pressure to secure to vehicle.



5. Repeat steps 1-3 for all door handles.

Note - Do not wash vehicle for 24 hours following installation.

LIMITED 12 MONTH WARRANTY Applies to Rugged Ridge by Omix-Ada Inc. Products

Rugged Ridge Off Road (the Company) warrants to the original purchaser of this product that should the product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 MONTHS from the date of original purchase, such defect(s) will be repaired or replaced or credited at the Company's sole option.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. Dated bill of sale), specification of defect(s) to the place of purchase or, with prior approval from the Company (Return Authorization Number is required), freight pre-paid to the Company address listed below.

This warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident or by acts of nature. THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERHCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN THE PERIOD OF 12 MONTHS FROM DATE OF ORIGINAL PURCHASE.

IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Omix-Ada Inc. 460 Horizon Dr. Suite 400 Suwanee, Georgia 30024